

Duplication is prohibited. 複製禁止



DOI: 10.48708/4756027

HYDROGENIUS DATABASE
— Hydrogen Transport Properties —

No. B29

Database of Hydrogen Transport Properties of JIS-SCM435 Low-Alloy
Steel for Use in a Storage Cylinder at a 35-MPa-Hydrogen Type "A"
Station

August 2011

Research Center for Hydrogen Industrial Use and Storage (HYDROGENIUS)
Kyushu University - JAPAN

HYDROGENIUS DATABASE No. B29

Database of Hydrogen Transport Properties of JIS-SCM435 Low-Alloy Steel for Use
in a Storage Cylinder at a 35-MPa-Hydrogen Type "A" Station

Year of publication: 2011

Kyushu University	Technical Advisory Committee
HYDROGENIUS	TAKAKI Setsuo (Chair - Kyushu University)
Fatigue and Fracture Department	EGUCHI Tohru (Suzuki Motor Corp.)
MATSUOKA Saburo (Leader)	HATANO Masaharu (Nippon Steel & Sumikin Stainless Steel Corp.)
MATSUNAGA Hisao	HIROTANI Ryuichi (Iwatani Corp.)
YAMABE Junichiro	IMAKAWA Kazunari (Nisshin Steel Co., Ltd.)
HAMADA Shigeru	KANEZAKI Toshihiko (Honda R&D Co., Ltd.)
ITOGA Hisatake	KAWAMURA Nobuyuki (HAMAI INDUSTRIES LTD.)
AWANE Tohru	KIMURA Kiyoshi (TATSUNO Corp.)
YOSHIKAWA Michio	KISHI Kenji (TOKICO TECHNOLOGY LTD.)
HYDROGENIUS	KUBOTA Kazumasa (Aichi Steel Corp.)
SUGIMURA Joichi (Director)	MAEDA Takashi (JRCM)
KURIYAMA Nobuhiro (Vice-Director)	MIYAGAWA Kazuo (Honda R&D Co., Ltd.)
	MIYAKANE Hirotake (AIR LIQUIDE Japan Ltd.)
	NANBA Shigenobu (Kobe Steel, Ltd.)
	OHMURA Tomohiko (Nippon Steel & Sumitomo Metal Corp.)
	SAKAKIDA Akihiko (Nissan Motor Co., Ltd.)
	SHINOHARA Mikiya (Nissan Motor Co., Ltd.)
	TAKAGI Shusaku (JFE Steel Corp.)
	TAKAMI Masayoshi (Toyota Motor Corp.)
	TANAKA Hidenori (YAMATO)
	WATANABE Osamu (KITZ CORP.)
	YAMAGUCHI Norikazu (Taiyo Nippon Sanso Corp.)
	YAMAMOTO Hiroshi (Azbil Corp.)
	YAMAMOTO Osamu (Toyota Motor Corp.)
	YANAGISAWA Yusuke (The Japan Steel Works, Ltd.)
	YOSHIKAWA Nobuhiro (University of Tokyo)
	YOSHINAGA Tomofumi (Nissan Motor Co., Ltd.)

Users' acceptance of these terms: This HYDROGENIUS DATABASE is available without charge on these express terms that users who view, access, download to use this HYDROGENIUS DATABASE expressly agree to these terms of use indicated herein. If you do not accept these terms, you must not access, view or download to use for any purpose.

Disclaimer: Unless otherwise stated, any products designed and/or fabricated in accordance with this HYDROGENIUS DATABASE are neither endorsed by nor affiliated with HYDROGENIUS. To the extent permitted by laws of Japan, HYDROGENIUS excludes, whether express or implied, all conditions, warranties, representations or other terms which may apply to this HYDROGENIUS DATABASE or any content on it. HYDROGENIUS will not be liable for any direct or indirect losses/damages of any consequence resulting from, whether in contract, tort (including negligence), breach of statutory duty or otherwise whether foreseeable or not, or arising under or in connection with use of or reliance on this HYDROGENIUS DATABASE and any content displayed on this HYDROGENIUS DATABASE, or for inability to use this HYDROGENIUS DATABASE thereon. There are no express or implied warranties of merchantability or fitness for a particular purpose regarding the use of this HYDROGENIUS DATABASE and any content displayed on this HYDROGENIUS DATABASE.

All rights reserved: No part of this HYDROGENIUS DATABASE or any of content displayed on HYDROGENIUS DATABASE may be reproduced or republished in any format, stored in any electronic or alternative retrieval system, or else modified, transferred, distributed, circulated, transmitted or exploited in any manner, without the prior written permission of HYDROGENIUS. All company and product names, design rights and equipment that are featured, used or cited in this HYDROGENIUS DATABASE shall remain any of intellectual property and/or registered trademarks of their respective companies/owners.

Termination: HYDROGENIUS reserves the rights to modify this HYDROGENIUS DATABASE in any way or discontinue providing any or all of this HYDROGENIUS DATABASE without notice.

Duplication is prohibited. 複製禁止

HYDROGENIUS may require the termination of any and all display distribution or other use of any or all of this HYDROGENIUS DATABASE for any reason.

These terms of use, its subject matter and formation are governed by the laws of Japan, and the courts of Japan will have exclusive jurisdiction in case of dispute or claims related to this HYDROGENIUS DATABASE.

Any personal information or data collected from your access to this HYDROGENIUS DATABASE will be handled according to the policy of Kyushu University Institution Repository (QIR) and Privacy Policy of Kyushu University which can be found at <https://www.kyushu-u.ac.jp/en/website/privacypolicy>.

Copyright © 2021

Kyushu University, Research Center for Hydrogen Industrial Use and Storage (HYDROGENIUS)

744 Motooka, Nishi-ku, Fukuoka-city, Fukuoka, 819-0395, JAPAN


Tel.: +81-92-802-3921 Fax: +81-92-802-3928

E-mail: db@hydrogenius.kyushu-u.ac.jp

Database of Hydrogen Transport Properties of JIS-SCM435 Low-Alloy Steel for Use in a Storage Cylinder at a 35-MPa-Hydrogen Type "A" Station

1. MATERIAL

Table 1. Processing details and related properties.



Hot-forged cylinder → Cold-forming of head and tail → Quenching-tempering
 → Hardness measurement → Screw processing → Shot-blasting
 → Inspection of inner and outer surfaces → Pressure proof-test → Stamping → Painting

Table 2. Chemical composition of SCM435.

			Element (mass%)						
			C	Si	Mn	P	S	Cr	Mo
Product Analysis	Present Material ¹⁾	Center Inside	0.37	0.22	0.84	0.012	0.005	1.15	0.24
			0.38	0.22	0.79	0.006	0.004	1.1	0.23
Ladle Analysis	Present Material ²⁾		0.35	0.20	0.77	0.008	0.003	1.05	0.20
	Requirements ³⁾	Max.	0.38	0.35	0.85	0.030	0.030	1.20	0.30
		Min.	0.33	0.15	0.60			0.90	0.15

¹⁾ As performed at HYDROGENIUS.

²⁾ As reported by the manufacturer.

³⁾ As per JIS G 3441:1988, "Alloy Steel Tubes for Machine Purpose".

Table 3. Heat treatment.

Quenching	Tempering
Barrel-furnace	Truck-furnace
860°C, Water-spraying	630°C, Air-cooling
3.60~3.95 BHD (Target hardness)	

It should be noted that the following data are identical to those featured in HYDROGENIUS DATABASE No.4: Tables 1, 2, 3, 4 and 5.

2. MECHANICAL PROPERTIES

Table 4. Tensile properties.

$\sigma_{0.2}$: 0.2% Proof strength
 σ_B : Tensile strength
 ε_u : Uniform elongation
 ε_f : Total elongation
 φ : Reduction of area
 C_H : Hydrogen content

(a) Circumferential direction (C-specimens)

	Tensile properties					Hydrogen content
	$\sigma_{0.2}$ (MPa)	σ_B (MPa)	ε_u (%)	ε_f (%)	φ (%)	C_H (mass ppm)
Uncharged	671	824	7.9	20.4	71.6	0.0
Hydrogen-charged	682	823	7.9	21.0	66.6	0.3
	665	803	7.0	18.8	71.6	0.3
	680	815	7.0	18.0	68.3	0.3

(b) Longitudinal direction (L-specimens)

	Tensile properties					Hydrogen content
	$\sigma_{0.2}$ (MPa)	σ_B (MPa)	ε_u (%)	ε_f (%)	φ (%)	C_H (mass ppm)
Uncharged	687	824	6.9	20.3	71.0	-
	679	815	7.5	23.6	73.0	-
Hydrogen-charged	719	827	8.2	19.5	71.3	0.4
	707	838	7.5	19.5	68.9	0.3
	667	829	7.5	19.7	67.0	0.3

Table 5. Average value of Vickers hardness.


Vickers hardness
\overline{HV}
256

It should be noted that the following data are identical to those featured in HYDROGENIUS DATABASE No.4: Tables 1, 2, 3, 4 and 5.

3. HYDROGEN TRANSPORT PROPERTIES

Table 6. Hydrogen-charging and hydrogen-measurement conditions.

(a) Hydrogen-charging conditions.

Type of hydrogen-charging	Exposure to hydrogen gas at pressures of 94 ~ 100 MPa
Hydrogen-gas purity	99.999%
Hydrogen-gas temperature & holding time	358 ~ 359 K, Over 200 h
Specimens ^{1), 2)}	 <p style="text-align: center;">$D = L = 19 \text{ mm}, 7 \text{ mm}$</p>



¹⁾ Specimens were cut so as to be equal in diameter and in length.

²⁾ Surface-finishing was performed by circumferential-polishing using 2000-grade silicon-carbide paper.

(Table continues on the following page)

Table 6. Hydrogen-charging and hydrogen-measurement conditions. (Continued)

(b) Hydrogen-measurement conditions.

<p>Type of spectroscope</p>	<p>TDA (Thermal Desorption Analysis) Hydrogen detection accuracy : 0.3 Vol. ppm Amount of hydrogen molecule detection : 6.1×10^{-10} mol/min</p>
<p>Measurement methods and conditions</p>	<div style="text-align: center;">  <p>(a) Multiple-specimen measurement method. Measurement conditions: 100°C /h, 20°C ~ 520°C</p>  <p>(b) Single-specimen measurement method. Measurement conditions: 100°C /h, starting at 20°C, maintenance at 50°C, 70°C or 85°C, then increasing to 520°C.</p> </div>